

FAX FROM

TEKTRONIX AB

SWEDEN - FAX NUMBER: 46 8 986 105 - TELEPHONE: 46 8 292 110

Number of pages (including this one): 1

Date: March 13, 1991

To: Jon [redacted]
M/S: 47-790
FAX #: 503-627-2341

From: Håkan [redacted]

Subject: DSA602 + 11302

Hello again Jon !

[Redacted text block]

When doing the calibration with TEKCATS on an upgraded 11302 (F/W version 3.1 as in my question from yesterday) should the instrument be treated as an 11302 or 11302A ? Is it important which ? I'm using version 2.19 of TEKCATS is this the latest/final version ?

Best regards

Håkan
Håkan

March 14, 1991

To: Hakan [redacted] Tek Sweden
From: Jon [redacted] 47-790
Subject: DSA60X fw/11302 cal sw

Hello Hakan,

[Redacted text block]

When using the Tekcats cal sw version 2.19. with a 11302 (ver 3.1) treat it as a 11302A. You will get an error message at the beginning of the program. Ignore this warning and continue with the calibration process. Version 2.19 is the last version of TEKCATS sw. There will be no new releases.

I hope that I did a better job of answering your questions this time. I appreciate the followup fax so that I could respond accordingly.

Regards

Jon [redacted]
OG Service Support
FAX: 503-627-2341
Phone: (503) 627-2292
Email: Jon [redacted]

Same applies to 11301 vs 11301A (V3.1)

Approved By M. Rafiq
[Signature]